

ROOF FITTERS: Ensure this guide is passed to your plasterer to ensure a quality install



SEE p41 FOR GUIDANCE

V17 | January 2026

LIVINROOF INSTALLATION GUIDE

Solid roof conservatory conversion

Dear Customer,

Thank you for choosing the Ultraframe Livinroof solid replacement product. This guide is designed to make fitting as straightforward as possible. Before you commence installation of the roof, please take a moment to read the 'quick view' below then read the rest of this guide. Video links are provided for you to view on site from your smart phone.

THIS GUIDE IS WRITTEN ON THE BASIS THAT THE SURVEYOR HAS UNDERTAKEN CORRECT CHECKS FOR THE CAPABILITY / STRUCTURAL PERFORMANCE OF ANY EXISTING FRAMEWORK / WALLS / FOUNDATIONS TO VERIFY THEY ARE FIT FOR PURPOSE

Any feedback - positive or negative - is welcomed so we can make our systems even better.

Please contact the Tech Support Team on
01200 452918 or email techsupport@ultraframe.co.uk



CONTENTS


Quick view installation sequence	2 - 3	Installation - ridge board	43
Fitment and tools	4	Installation - ridge board - glazed panels	44
Pre-installation checks & general points	5	Installation - cloaking panel ridge	45
Handling aluminium products	6	Installation - plastering and plasterboarding	46
Speedlock removal	6	Appendix 1 - tie bar and tie beam	47 - 49
hup!	7	Appendix 2 - bolster bars (glass both sides)	50 - 57
0.12 Thermal Improvements	8 - 9	Appendix 3 - box gutter installation	58 - 64
Product overview - cross section drawings	10 - 15	Appendix 4 - valleys	64 - 70
Components parts list - additional to standard glazed roof	16		
Installation - of main roof	17 - 29	Appendix 5 - ventilated wall plate	71 - 72
Insulation slabs	30	Appendix 5 - half ridge installation	72
Components parts list - pelmet	31	Appendix 6 - gables	73 - 81
Gallows bracket pre-preparation	32	Appendix 7 - muntin - glass jointer - top cap removal	82
Installation - pelmet brackets	33 - 38	Appendix 8 - alternative ridge board detail	82
Installation - cloaking panel clips on glazing bars	39	Appendix 9 - glazing bar top cap removal	83
Installation - cloaking panel clips - eaves	40	Appendix 10 - Cleaning and maintenance	82
Installation - cloaking panels - eaves	40		
Installation - pelmet ladders	41	When installing roof vents or Cornice, please see the installation guide (supplied separate)	
Installation - pelmet ladders & 25mm board insulation	42		

QUICK VIEW INSTALLATION SEQUENCE

STEP	PAGE	KEY INFORMATION
A Fit eaves beam, gable beam, box gutters, Cornice lower, guttering, gable frame, gable firrings, gable wedges (Top & bottom)	A	N.B FIT THE GABLE FRAME BEFORE THE GABLE FIRRINGS
B Fit starter bars, ridge, hip or gable bars, transom bars, aluminium bolster bars, jack rafters, valley	B	
C Fit tie bars	C	N.B CHECK THE TIE BAR TYPE AND OPTIONS
D Fit struts, valley mineral wool and angle plate	D	
E Fit external flashing	E	
F Fit/glaze roof, solid panels, glass units inc. muntin bars and roof vent, glazing bar cappings, ridge bung, ridge capping & baffleseal	F	N.B THE BAFFLE SEAL IS AN ADDITIONAL PART OF THE RIDGE AND MUST BE FITTED IN ALL SITUATIONS
G Fit box gutter adaptors, complete guttering downpipes and clips, Cornice	G	
H Fit internal fascia board	H	N.B NO FASCIA CORNERS REQUIRED
I Fit 90mm insulation, valley insulation, ridge mineral wool & fill all gaps with mineral wool	I	
J If required (glazed areas) fit PVCu claddings to aluminium bolster	J	N.B THE FINISHING POINTS OF PVCu CLADDING IS CRITICAL, REFER TO LOCATION PLAN FOR SIZE & POSITION
K Fit insulated internal pelmet brackets, insulated internal pelmet frame, ridge end bracket (if required), ridge board, ridge cloaking screen (if glazed), all battens, rad end cloaking screen (if glazed), alter frame for lighting.	K	N.B IF GLAZING AREA, FIT POLYCARB CLOAKING SCREEN CLIPS TO FASCIA, SUPPORT CLIP TO SCREEN IF BOLSTERED. FIT CLOSURE TRIMS BETWEEN BRACKETS' THEN FIT POLYCARBONATE CLOAKING SCREEN. DUE TO THE NATURE OF THE 'SANDWICH' CONSTRUCTION, THE CORRECTLY RATED WIRING/LIGHT FITTINGS MUST BE USED.
L Fit 25mm insulation (screws & washers), foil tape joints. Fit mineral wool into insulated internal pelmet frame	L	
M Fit plasterboard (12.5mm foil - backed) to 1. insulated internal pelmet bottom, 2. Ridge board, 3. Ceiling pitch, 4. insulated internal pelmet vertical	M	N.B INSTALL IN SEQUENCE ORDER, USE 12.5MM FOIL BACKED PLASTERBOARD

The core of the guide shows how to install a typical Georgian 4x4 roof with Jack Rafters and fitted with solid panels and glazing.


The insulated internal pelmet can be fitted in two positions, A&B.
This guide is mainly based on details A



Ladder framework terminates on Fascia - standard eaves

Here we have the ladder steelwork terminating on the PFTB plank fascia (using standard eaves beam).

This detail is used when there are window frames around the complete perimeter and where there are no box gutters included in the design.



Ladder framework terminates below Fascia - standard eaves

This detail is used when there is a box gutter included in the design. The steelwork ladder terminates underneath the PFTB plank fascia.

Please note the following:

- window frames all round, a frame add-on of at least 30mm must be used.

ALWAYS SAFELY DISMANTLE THE EXISTING ROOF AND DISPOSE OF THE OLD MATERIALS IN A SUSTAINABLE WAY

TOOLS REQUIRED

Eaves to frame fixings, host wall fixings and ridge top cap flashing trim screw not supplied.



8, 10, 13mm
Socket Spanner



Deadblow Hammer
or White Rubber
Mallet



No. 2 Pozi-drive Bit



5mm Wide Flat
Blade Screwdriver



Hack Saw



Drill/Screwdriver



Long nose pliers



Gasket Shears/
Snips



4.5mm Drill Bit
10mm Drill Bit



Sealant Gun



2 x 5mm Allen Keys
(Vic fixing kit)




17mm Open
Ended Spanner -
Tie Bars



Spirit Level
(magnetic useful
for internals)



Tape Measure



Anglefinder




Plumb bob



Adjustable Support Prop

MATERIALS YOU NEED TO SUPPLY:
12.5MM FOIL BACKED PLASTERBOARD & 50mm
DRYWALL SCREWS, GYPROC ANGLE BEAD RESIN
ANCHORS.

PRE-INSTALLATION CHECKS



If fitting new frames do not fix the frames down - pin only to the house wall (one fix per side) to allow the conservatory to 'float'.



Attach the glazing bar end cap fixing blocks - as access restrictions (box gutter situations) may prevent easy attachment later. NOTE: These are attached to the end caps when despatched from the factory.



MS Polymer




- Self cleaning glass



Low modulus
neutral cure

- Solid Panels
- Standard sealed units

Use the correct sealant on glazing



Check the condition of the host wall as this may affect the quality of the final installation. Check the host wall is plumb - any running in/out should have been accounted for by the surveyor. If not, the ridge and starter bars may require packing out with aluminium shims. Correct alignment in this area is critical to a successful installation

- Plumb frames/level ridge. Only use the specified fixings - never be tempted to substitute alternative sizes/gauges.

General points

Care should be taken when handling components that are seen by the homeowner, as surfaces may be scratched if not handled with care. Choose a suitable area for unpacking the components and always check them before fitting. Any claims for missing or damaged parts are only accepted in line with our standard terms and conditions of sale.

Health & safety

Site safety is paramount. The Construction (Design & Management) Regulations 2015 apply to the whole construction process, on all construction projects from concept through to completion. Compliance is required to ensure construction projects are carried out in a way that secures health and safety. The installation company shall be responsible for the safety of all of the fitting team, the customer and members of the public.

The Surveyor should have carried out a risk assessment to reduce risk on site and this should have been discussed with you prior to starting.

Please use safe working platforms and ladders that comply with BS EN 131. Always use equipment in line with manufacturers recommendations. Personal Protective Equipment - such as goggles, mask and ear defenders – should be used when, for example, grinding out for the flashing.

Careful consideration should be given to the safe disposal of all packaging – Ultraframe packaging is predominantly made from recycled materials and can be readily recycled.

Product

The roof kit is supplied with a location plan, a quality control check list for the box in which this guide arrives and, of course, this installation guide. The location plan is used to match individual components to their respective position on the roof. Our numbering convention always starts at the top left, against the house wall as you look from outside the conservatory back at the host wall.

The majority of aluminium and PVCu components contain identification codes, usually by inkjetting or labelling – should you need to re-order a part this should help.

Sealing

It is important to use the correct sealant when sealing the roof.

1. For the solid panels a low modulus neutral cure brand of sealant must be used
2. For the individual 'self cleaning' glass panels use MS Polymer sealant such as Rotabond 2000.

The Superstructure

Check the Dwarf wall or Plinth for being level all round. Ensure that all frames which abut the host wall are vertically plumb, which will then allow perfect alignment with the Classic eavesbeam. Before starting to install the roof, please check the condition of the host wall and whether it's plumb – depending upon what you find, these conditions can seriously affect the final integrity of the roof.

Technical Support

Tel: 01200 452918

Email: techsupport@ultraframe.co.uk

HANDLING ALUMINIUM PRODUCTS

PAINTED ALUMINIUM

PRODUCTS - PLEASE NOTE

All paints will 'chalk' to some extent and there will be a reduction in gloss level over time. (See Cleaning and Maintenance guidelines p42)




If storing in warehouse racking or on frails/roof racks, take care to support the products and do not over tension straps and ropes. When opening sealed packs, use a special box knife opener.

QUALITY EXPECTATIONS ON INSTALLATION.

Appearance: This is assessed based on the selection of the 'significant' (primary) surface. From a distance of 3m, stand at an oblique angle of 60degree and then defects such as blisters, runs, pin holes etc should NOT be seen.

Colour and gloss: Viewed from 5m, the coating must be of even colour and gloss with good coverage.



Grease marks, dirt and mastic spillage may be removed using soapy water. Take care when fitting aluminium products to not use excessive force.



If site cutting is necessary (drainage slots need inserting or a down pipe hole has to be cut) ensure all swarf is kept away from the painted surface and then seal with a primer/ corrosion inhibitor and then top coat. Alternatively, use a suitable gap sealant to prevent the onset of corrosion. These steps are critical in marine environments.

CAUTION- WHEN HANDLING ALUMINIUM FACED SANDWICH PANELS - USE PROTECTIVE HAND WEAR.

SPEEDLOCK REMOVAL



If you need to remove a glazing bar from the speedlock 2 socket assembly, remove the speedlock hood (if fitted) and release and lift the bar at the eaves end.



Gently lever up the upper deadlock.



Insert the 5mm wide flat blade screwdriver and gently push against the upper edge of the roller cam (marked yellow).




Gently pulling the bar away will automatically release the head of the speedlock.



Turn the whole bar over, then insert the screwdriver blade under the lower wedge lock. Lift to allow the wedge to ride back over the serrations to its original position.

HUP!

The Livinroof is compatible with the hup! walling system. For full details, see separate hup! technical guides.




A top tray runs along the top of the hup! walls underneath the eaves beam. The clips are secured into place by fixing through the top tray. Raked frames must be used on lean-to roofs as the walls cannot be raked and meet the panels/starter bar.

Internally the top tray meets the edge of the internal pelmet or it can be wider.



Lower the cill (not included) onto the walls. The internal face of the frames (if 70mm frames are used) is to sit 70mm inboard from the external wall steel datum (145mm from the internal). This is the outermost steel on the top tray.



Run a bead of sealant along the top of the cills.




Lower the eaves into position on the cill. Secure the eaves beam down through the cill and into the top tray using appropriate fixings (NOT SUPPLIED) at 450mm centres and within 200mm of the eaves beam ends. Once secured, fixing heads are to be sealed with an appropriate sealant.

LIVINROOF THERMAL IMPROVEMENTS

Additional Parts Supplied.



25mm phenolic insulation




TIFK025
Fixing Kit




LVBG240
25 x 40mm
Timber Battens


Transoms Cross Section




Hips Cross Section



Starter / Gable Cross Section




Valley Cross Section




LIVINROOF THERMAL IMPROVEMENTS

Transom Solid / Solid




Secure the first layer of 25mm insulation using the LVIK025 fixing kit. If solid / glazed, fix LVBG240 timber batten to the underside of the first layer of insulation. Apply the second layer of 25mm insulation beneath the first and secure with the provided TIFK025 fixing kit.*

Starter



Secure the first layer of 25mm insulation using the LVIK025 fixing kit. Apply the second layer of 25mm insulation beneath the first and secure with the provided TIFK025 fixing kit.*

Transom Solid / Solid Gable




Secure the first layer of 25mm insulation using the LVIK025 fixing kit. Screw CHA405/1 steel C channel to the side of the chambered box on the underside of the first layer of insulation. Apply the second layer of 25mm insulation beneath the first pushed into the C channel and secure with the provided TIFK025 fixing kit.*


Transom Solid / Glazed



Valley



Standard Hip




Fix provided 25mm x 44mm timber batten LVBG240 to the centre of the hip bar box section (1). Secure the first layer of 25mm insulation up against the fitted timber batten using the LVIK025 fixing kit. Apply the second layer of 25mm insulation beneath the first, overlapping the timber batten and secure with the provided TIFK025 fixing kit.*


*Ensure that all lower insulation joints are taped with foil sealing tape LVFT045.

PRODUCT OVERVIEW

Glazing Bar Suite



Strut (fitted to every bar on every roof)



PRODUCT OVERVIEW


THESE ITEMS ARE SPECIFIED ON THE RELEVANT DESIGN



STRUCTURAL MOULDING EAVES/HOST WALL: Where the eaves beam sits against the host masonry wall, it has a structural moulding attached to the eaves beam. This has three fixing positions cast into it to allow attachment into masonry – choose the hole that directly lines up with solid masonry and attach using one resin anchor suitable for substrate / loads (other anchor types may be suitable).



SUPER DUTY EAVES BRACKET: Where the Super Duty Eaves beam has been specified, bracket SEWC002 (left and right handed) will be supplied. This should be fitted to the eaves beam using X3 M5 X 12 taprite screws (supplied). This should then be fitted to the host wall using a minimum of 4 fixings suitable for the substrate (not supplied).



RIDGE HANGER / COMPRESSION PLATE: The ridge hanger/compression plate is attached to the host wall. Using two resin anchor bolts (not supplied).

THESE ITEMS ARE SPECIFIED AUTOMATICALLY ON SOME PROJECTS (IF STRUCTURALLY REQUIRED)



Each eaves corner (90°, 135° and 150°) is supplied pre-fitted with an additional standard cleats(2 in total).



On Georgian hip bar, a butterfly cleat is laid over two captivated roofing bolts.



An aluminium bolster beam is factory stitched and extends along the entire length of the ridge and acts as one with the existing aluminium ridge body to virtually eliminate deflection.

SYSTEM OVERVIEW

Transom Bar - solid/glass - on fascia



SYSTEM OVERVIEW

Box Gutter - solid/glass - below fascia



Transom Bar - solid/glass - below fascia



Box Gutter - solid/solid - below fascia



*** IMPORTANT - ALL INTERNAL PELMETS TO BE FULLY INSULATED WITH MINERAL WOOL**

*** IMPORTANT - ALL INTERNAL PELMETS TO BE FULLY INSULATED WITH MINERAL WOOL**

SYSTEM OVERVIEW

Valley - solid/solid



SYSTEM OVERVIEW

Gable - glass

PLEASE DO NOT ORDER / MANUFACTURE GABLE FRAMES BEFORE DISCUSSION WITH ULTRAFRAME TECHNICAL SUPPORT ON 01200 452918.

Gable frame sizes on Livinroof roofs are different to regular glazed Classic Roofs.




Hip - solid/solid



Gable - solid

PLEASE DO NOT ORDER / MANUFACTURE GABLE FRAMES BEFORE DISCUSSION WITH ULTRAFRAME TECHNICAL SUPPORT ON 01200 452918.

Gable frame sizes on Livinroof roofs are different to regular glazed Classic Roofs.



*** IMPORTANT - ALL INTERNAL PELMETS TO BE FULLY INSULATED WITH MINERAL WOOL**


*** IMPORTANT - ALL INTERNAL PELMETS TO BE FULLY INSULATED WITH MINERAL WOOL**

COMPONENT PARTS LIST - ADDITIONAL TO STANDARD GLAZED ROOF



INSTALLATION

IF YOUR DESIGN FEATURES GABLE FRAMES SEE p69 - 77




Apply a continuous bead of sealant to the front and rear inner legs of the window frames. Scale over the holes left by any old fixings. Fit the initial piece of eaves beam ensuring that the inside face of the eaves beam is flush with the inside face of the window frame.

IF A BOXGUTTER IS TO BE FITTED, IT IS STRONGLY RECOMMENDED THAT A 30MM FRAME ADD ON IS USED AT THIS STAGE.



Place the next section of eaves beam into position, by slotting the corner cleat on the adjacent piece of eaves beam into the first piece. Ensure a seal is placed between any joints in the eaves beam.



Using the pre-drilled pilot holes, drill two 4.5mm holes through the corner cleats.

ON SOME PROJECTS A DOUBLE CLEAT IS SUPPLIED & A FURTHER BUTTERFLY CLEAT (SEE P8) N.B. ENSURE THE UNDER GUTTER TRIM IS FITTED TO THE EAVES BEAM AND ALL THE BOLTS ARE IN SITU PRIOR TO FIXING TO THE FRAMES. **IF CORNICE IS BEING FITTED REMOVE UNDER GUTTER TRIM**




Securely fit the two M5 x 12mm taptite screws.



Using the pre-drilled pilot holes, drill two 4.5mm holes through the corner cleats.



SECURELY FIT THE EAVES BEAM TO THE FRAMES USING ONE OF THE FOLLOWING 3 METHODS:
Use 38mm X 4.8mm screws (not supplied) in the position shown. Fix down at 450 centres and within 200mm of each corner. For 60mm frames use the inner eaves extrusion line and outer line of 70mm frames.




When using the Victorian Fixing Kit drill a 10mm hole through the base of the eaves beam and completely through the head of the window frame. Ensure that both sides of the 10mm hole are accessible for Allen key fixing. Use a 5mm Allen Key to tighten the fixings. The eaves beam should be fixed at 450mm centres and within 200mm of each corner. **THIS IS ULTRAFRAME'S RECOMMENDED FIXING METHOD**



ALTERNATIVE PREFERRED METHOD IF NO REINFORCING
Behind the head of the screw, use a 20mm washer so that the thread is biting into the aluminium eaves beam.

NOTE: Trim back any screw points protruding through the eaves beam to make flush.

INSTALLATION



Once the eaves beam is secure, run a bead of sealant down the joint where the eaves beam sections meet and where the eaves abuts the host wall. **YOU MAY AT THIS STAGE INSTALL THE GUTTERING PRIOR TO FITTING THE GLAZING BARS - If fitting Cornice fit the base of the Cornice to the eaves beam before the guttering.**

Now take the ridge hanger/compression plate assembly. On the ground, away from the conservatory, offer up the first starter bar with the soaker trim pre-fitted. Fasten using the set screws provided – do not over tighten.

Take the second starter bar and similarly offer this onto the ridge hanger/compression plate assembly. Lift the whole "A" frame assembly and get ready to install it in its final position.


N.B. IF USING LOW PITCH FIRRING ON GABLE FRAME (BELOW 11°), THE FIRRING MUST BE FITTED BEFORE THE CORNICE BASE OR GUTTERING



Attach the starter bar using the nut, bolt and spring washer (included in the kit) to the eaves structural moulding. Finger tighten the nut to temporarily allow the assembly to hang.

To set the ridge, use an "angle fix" to check the starter bars are at the correct pitch. Chalk/pencil a line on to the wall to mark the pitch line.

Bolt the ridge hanger/compression plate to the host wall. **Drill the plate as required to line up with solid masonry using the two resin anchors suitable for loadings/substrate. If necessary, use aluminium shims to pack out behind the plate.** Check the plate is vertical and securely fastened.



Support ridge body. Loosen the "crocodile jaw" bolts on the underside of the main ridge body – ensure it is supported at the front whilst it is gently guided onto the top half of the 'crocodile jaw'.


Note: The starter bar is NOT attached (bolted) to the ridge body.

The ridge body should ideally sit 20mm back from the house wall (or 12mm from the front plate), this allows the compression plate to evenly distribute ridge loads into the host wall (max tolerance 50mm). **If the host wall is out of plumb, pack out behind the starter bars and use the longer bolts provided. This ensures the starter bars are at 90° to ridge body (and not tapering).**

Ensure that the fixing on the eaves moulding and the nuts on the 'crocodile hanger' are tightened up.

Also ensure the bolts at the top of the starter bar, are tightened up.

INSTALLATION



Continue to support the ridge and offer up the transom glazing bars (above), loosely attaching using the roofing nuts and bolts supplied. Ensure the rain baffle upper leg is lifted prior to placing the glazing bars.

Offer up the hip bars.

Using Speedlock 2 on the glazing bar end, offer the 'ball' into the matching socket.





Attach bar at eaves position. Using your thumb push down the upper dead lock so it's flush. **YOU MUST NOT PUSH UP THE LOWER WEDGE LOCK UNTIL STEP 36.** To remove the bar, lever up the dead lock using a flat blade screwdriver, then insert the screwdriver to release the socket latch.

Next, attach the speedlock hood over each bar, sliding it under the co-extruded gasket of the glazing bar undercladding.

Push down to locate, with the final position abutting the front edge of the die cast end.

IF YOU NEED TO REMOVE A Speedlock, SEE P6




Continue to attach all the glazing bars using the location plan provided to check each bars final position with its corresponding label.

Now start on the jack rafters. The two part jack rafter kit will already be fitted to the hip and jack rafter bars. Again refer to the location plan and corresponding labels attached to the parts.

Each jack rafter kit is supplied with a number of washers. Trial fit the jack rafter and check that the glazing platforms are level. Adjust if necessary by adding or removing washers between the two part connecting kit, then tighten the nut.

GUTTER INSTALLATION

Fig. 1 GUTTERING ASSEMBLIES



IMPORTANT:

NOTE: DO NOT push fit any union onto gutter as this can result in leaks.



Ensure all lengths of gutter fit to the marked insertion line seen in all unions and box gutter adaptors. (See Fig. 2)

Ensure to lubricate all rubber seals prior to inserting the gutter.

Must not slide gutter into union must always roll and lock.

DO NOT Sealant Seal, this would prevent expansion/contraction.

If the gutter is not allowed to freely expand, distortion can occur.



Gutter brackets

Measure & fit all gutter brackets supplied with the kit at maximum 750mm centres and maximum 150mm from Unions and all stop ends. (See Fig. 1)

Position valley 90° internal angle if required. (See Fig. 1 general finished assembly)

NOTE: It is difficult to fit valley 90° Internal if the valley is already installed.

2a



Pre build up gutter assembly

Position the external 90° gutter angle onto the eaves beam followed by any union/outlet. Then measure between the insertion lines (clearly marked on the union/outlets) and cut the gutters to length. **Ensure to lubricate all rubber seals prior to inserting the gutter into position** then snap the integral clips fitted to the unions/outlets over the gutter.

2b



Insert gutter assembly and roll into position, critical to locate the back edge of each section of gutter into the slot in the gutter bracket first.

NOTE: DO NOT push fit any union onto gutter as this can result in leaks.

GUTTER INSTALLATION

2c



Insert gutter assembly and roll into position, critical to locate the back edge of each section of gutter into the slot in the gutter bracket first. Then clip the front of the bracket into the lip of the gutter. Finally, slide the fixing block into place to lock out the gutter.

NOTE: DO NOT push fit any union onto gutter as this can result in leaks.


3



Assemble & cut gutter to size - If over 4000mm span then the gutter must be split by a straight union. Insert gutter assembly and rotate into position (see Step 2). DO NOT slide gutter into union must always roll and lock.

NOTE: Sliding can result in damage to the seal

4



Build up gutter assembly; gutter & 135° union. Snap the integral clips on the unions over the gutter assembly and rotate into position (see Step 2). DO NOT slide gutter into union must always roll and lock.

NOTE: Remember to work to the insertion lines.

2d



90° angle to overhang and then slide the gutter assembly towards the host wall until flush.

5



Build up gutter assembly; gutter & 135° union. Snap the integral clips on the unions over the gutter assembly and rotate into position (see Step 2). DO NOT slide gutter into union must always roll and lock.

Insert gutter assembly into brackets using "step 2b" assembly methods. 135° angle to overhang then.


135° angle to overhang, Slide gutter assembly towards 90° union and then snap the integral clips on the unions (Similar to step 2c).

NOTE: DO NOT slide gutter into union must always roll and lock.

6



Fig. 2



This should be the final step in the gutter system installation for a Georgian or Victorian, as the opposing side will be repeated by the previous steps within this guide. The gutter will essentially meet up at this step.

Cut gutter to length and insert gutter assembly into brackets using "step 2b" assembly methods.

NOTE: DO NOT slide gutter into union must always roll and lock.


INSTALLATION



Ensure the window frames are plumb.




Ensure the ridge is level.




Check that the pitch of the roof is correct. Your Surveyor should have provided a drawing/a copy of the roof confirmation which displays the pitch.



Check that the starter bar and first transom bars are parallel.




Fix starter bar back to the host wall using anchor bolts suitable for the substrate (not supplied). A minimum of 4 fixings are required: 2 at the eaves, 1 inboard and 1 outboard as shown; 1 within 200mm of the ridge; plus a minimum of 1 more equidistant between the eaves and ridge. Pack out to support the starter bar behind each fixing before fitting the correct resin anchor (or other suitable alternative).




Finally when all is level and plumb, use your thumb to push up the lower wedge which locks into closed position. The roof is now set.

FLASHING

It is at this stage that the stepped flashing is re-dressed. LEAVE APRON FLASHING UNTIL LATER.



Seal the area where the co-extruded gasket on the hip bar butts against the co-extruded gasket on the jack rafter.




Now glaze the side frames before glazing the roof - this provides additional rigidity whilst working above. INSTALL TIE BARS(S) BEFORE GLAZING.



Take the 'soft touch' hub weathering shield. It fits by lifting the flaps on the ridge rain baffle to insert. NOTE: The weathering shield will need to be trimmed to suit to fit snugly. See p19/20 for trimming information.

INSTALLATION



The rain baffle should nestle neatly to form a continuous weather tight joint.



For each glazing bar, 'snip' two small cuts in the weathering shield and then a horizontal cut to remove 'flap' which facilitates the top cap sliding under.

36

Now glaze the side frames before glazing the roof - this provides additional rigidity whilst working above. **INSTALL TIE BARS(S) BEFORE GLAZING.**



GEORGIAN INSTALLATION - WEATHERING SHIELD CUTTING DETAIL

READ ME FIRST

UP TO 3 STEPS MAY BE REQUIRED

In certain situations it may be necessary to make modifications to the HUB Weathering Shield on site.

Please refer to the table shown to see which steps need to be taken



ROOF PITCH	GLAZING THICKNESS	BARS TO FINIAL	BARS NOT TO FINIAL
15 - 24	25mm	FIG. 1	FIG. 1 + FIG. 4
	35mm	FIG. 1 + FIG. 3	FIG. 1 + FIG. 3 + FIG. 4
25 - 30	25mm	NO CUTTING REQUIRED	FIG. 4
	35mm	FIG. 3	FIG. 3 + FIG. 4
31 - 40	25 mm	FIG. 2	FIG. 2 + FIG. 4
	35mm	FIG. 2 + FIG. 3	FIG. 2 + FIG. 3 + FIG. 4

FIGURE 1 - APPLIES TO ALL ROOFS BELOW 25° PITCH





FIGURE 2 - APPLIES TO ALL ROOFS BELOW 30° PITCH





FIGURE 3 - APPLIES TO ALL ROOFS WITH 35MM GLAZING





FIGURE 4 - APPLIES TO ALL ROOFS WITHOUT A GLAZING BAR AT THE FINIAL POINT



This step allows glazing to run through when there is not a bar at the finial point.


With all other necessary preps complete, offer up the Weathering Shield into position. Using a straight edge (as shown), project and mark a line ('A') using the glazing 'V' groove (indicated inset) parallel with the centre of the bar closest to the finial point.

Mark line 'B' – this should intersect line 'A' and line through with the 'upper edge of block (25mm glazing) or '35mm dashed line' (35mm glazing) – see below.


Mark line 'C' – this should intersect line 'A' and the virtual 'MIDPOINT' – see below.

Remove segment and repeat on opposite side.

25mm GLAZING



35mm GLAZING




INSTALLATION - STRUTS

STRUTS AND TIE BARS


(every roof has struts)
(specified)

BOTH MUST BE FIXED BEFORE ROOF PANELS ADDED (See p43-46 for tie bar arrangements)



Lift strut into position – check level and fix using Hex head drill screws, 3 fixings per side (12 in total). Attach all struts at this stage.



RRS025
Hex Head Drill screw
5.5mm x 25mm




FIT RADIUS END BRACKET IF SPECIFIED
If a glazing bar is set back from the finial point by more than 150mm, a 2-piece radius end bracket is specified to attach the ridge board (see page 39) attach top 'L' shaped hanger bracket to the ridge body as shown, using 2 X Hex head screws (supplied).



Then attach bottom hanger plate to 'L' shaped bracket, ensuring that its bottom face lines through with the underside of the struts.
NOTE: It may be necessary to trim back the 'L' shaped bracket if it protrudes below the plate.




Now is the time to fit panel end profile. Take the painted profile and protect its surface. Apply a bead of relevant sealant (MS polymer on self cleaning glass). Slide into position on panel, wipe clean any sealant from surface.



Now it is time to start fitting panel clips. Snap off appropriate handed clip (left hand illustrated). Handing marked on base of clip. Line up the rounded edge on base plate next to central web of glazing bar then tuck neatly under gasket side of bar. Rotate clip into position. Push the grommet over the post as shown.



Slide the complete assembly down the glazing bar, using the endcap fixing block as the 'stop'.



Tease the 'tail' of the glazing support trim tape free (ready to be pulled away when the sealed unit is finally in position).




Centralise the glazing between the glazing bars. If necessary pack it out on each side - press it down onto the support trim.

INSTALLATION



Ensure the glazing end profile sits snugly behind the grommet. Now, using the fixing provided screw down into the bar as shown. Ensure clip offers maximum support to panels at all times.



THIS STAGE SHOULD HAVE BEEN PREPARED IN THE FACTORY. If not take the aluminium top caps and lay them onto a protected surface. Slide clips into each bar - position down from ridge / eaves at a max centre of 100mm and then at 500 centres (max) inbetween. **N.B. AT RADIUS END, IT MAY BE NECESSARY TO SLIDE CLIP FURTHER DOWN TOP CAP TO ENSURE ENGAGEMENT WITH GLAZING BAR**




Lift the rain baffle leg and position top cap.




Using the heel of your hand, push down on the top cap to engage the clips, working from ridge to eaves. Ensure the rubber gaskets are full compressed for a watertight seal. NOTE: on longer bars it may be necessary to use a soft mallet and timber block.

IF YOU NEED TO REMOVE A TOP CAP, SEE PAGE 78




Now on the Georgian hip bar tap the glazing bar top cap up until the cut out sits centre to the jack rafter fixing.




Seal around the notched Georgian top cap ready to receive the jack rafter capping.



Drill a 6mm hole through the aluminium top cap. Use the fixing provided (CRN010) to attach the top cap to the glazing bar. (Not required if using cornice with wire ties).




Ensure the jack rafter top capping is lined up correctly (as above) before knocking the top cappings into position.




The jack rafter top capping should sit tightly up to the hip bar top capping as shown.


INSTALLATION



58
Seal around the joint on the jack rafter capping when complete.




59
Carefully point the corners on each side of the capping where the gaskets abut each other.



60
Seal around the top of each glazing bar top capping where it meets the rain baffle. Next, run a bead of sealant along the edge where the glazing meets the rain baffle.

INSTALLATION




67
Apply a bead of sealant into the channel of the ridge flashing trim before fitting and then slide into position.



68
Screw the flashing trim to the ridge top cap through the screw port. Use a 4.2mm x 13mm self drilling screw (not supplied).



69
Apply a generous amount of sealant to the back edge of the flashing trim.



61
Seal around each glazing bar top capping where it meets the inner wall of the 'soft touch' moulded weathering shield.

Also apply a bead of sealant to the top edge of the weathering shield so that the ridge capping will seal against it when fitted.



62
Run a bead of sealant in the position shown where the 'soft touch' moulded weathering tray meets the ridge body.




63
An aluminium extrusion is provided to give an additional seal at the ridge. Sealant seal along the length of the 'V' slot.

AT THIS STAGE FIT THE BAFFLESEAL




70
Offer up the complete ridge capping onto the roof.



71
From the inside of the conservatory insert the snap off tommy bar into the T bolt.




72
Twist through 90° to locate the T bolt into the ridge capping.




64
Then offer up the extrusion and attach to the rain baffle. Seal into soft touch moulded weathering shield and host wall.



65
Fit the glazing bar end caps by sliding onto the fixing blocks. Push fit the insert into the end cap.



66
Now for the ridge top cap - Cut back the T bolt slot on the underside of the ridge top capping by 40mm.




73
Pull down on the T bolt and tap the fixing wedge into place to secure the T bolt. Cut off the excess T bolt below the fixing wedge.




74
Attach fascia board to bars built into the eaves beam.

IF YOUR DESIGN FEATURES
A VALLEY SEE APPENDIX 4


INSTALLATION - INSULATION SLABS - PELMET



Now moving onto the installation of the insulation. Take the 90mm insulation board – each part is numbered/lettered to identify where it goes (label always to the inside of the conservatory). Spot the board with sealant.




Insert the board into position between bars and ensure sealant 'grabs'.



Fill ridge voids – including the ridge radius end – using the mineral wool supplied (2 x 12m x 190mm wide rolls). In jack rafter positions, use a piece of mineral wool to ensure the potential for cold bridging is minimised.


COMPONENT PARTS LIST




CHA405/1
Perimeter Channel - PIERCED
CHA405/2
Perimeter Channel



CHA405/3
Crossrail Channel



Bolster Corner Infill



CHAB001
Transom Bracket



CHAB090
Georgian Hip Bracket




CHAB003
Hip Bracket Adjustable



CHAB011
Splay Bar Bracket Assemble



CHAB013
Closure Trim Support Bracket
LH (Bolster)



CHA009
Bolster Transom Bracket



CHA010
Bolster Hip Bracket Assembly



CHA012
Bolster Splay Bar Bracket



CHA006
BAG OF 25 - M4 x 13 Self Drill
Philips Wafer Head



CHA007
BAG OF 25 - 4.2 x 19 Self Drill
Philips Head Screw



CHA008
BAG OF 25 - 4.8 x 32 Self Drill
Philips Pan Head



CHA002
Poly Panel Spring Clip



CHA015
Super Duty Eaves Poly
Support Clip



CHA200/7
Vent Foam



CHA165 or CHAA265
Gallows Packer 165 or 265



CHA300/GR/4
1.25mm Plaster Stop Edge
Bead - Painted




CHA005
Single Tie Bar Cover

Should you find damaged or missing components, please always reference replacements with both a parts code (see above) and/or its position on the location plan. This will help with the speedy resolution of any issues.



This is how final installation should look.




N.B. IT IS CRITICAL TO POSITION THE PVCU CLADDING 350MM AWAY FROM THE RIDGE

POLY, LUVGS & PST OFFSETS


Bolster Offsets

(DATUM OFFSET
FROM TRANSOM
SIDE WHERE
POSSIBLE)




Hip Bar Offsets

(DATUM OFFSET
FROM TRANSOM
SIDE WHERE
POSSIBLE)




Starter+Gable Bar Offsets




PRE - PREPARATION - GALLows BRACKET


Packer / Spacer slips over




Finished installation you need to find



Box Gutter - 165mm




Box Gutter - 265mm



INSTALLATION - PELMET BRACKETS

IF YOUR DESIGN FEATURES GLAZING BOLSTERS SEE APPENDIX 2



OVERVIEW


NOTE: FOR GABLE FRAME
CONSERVATORIES – READ IN
CONJUNCTION WITH APPENDIX
6

IMPORTANT NOTE: Left (L) and right (R) dimensions are viewed internally.


STANDARD BRACKET BAR POSITION(s)	CHA001 (mm)	CHA003 (mm)	CHA090 (mm)	CHA01 (mm)	CHAA019L (mm)	CHAA019R (mm)
1-5, 7-8, 15	S-142					
6			S-97 L/R			
9				S-143 L/R		
10			S-176 L/R			
11	S-142				G-182 R	
12			G-248 L/R			
13	G-248					
14	S-142				G-182 L	

EXAMPLE
refer to separate location plan

PREFIX S: SOLID PANEL
PREFIX G: GLASS PANEL




GENERAL NOTE ON BRACKET FIXING 1: Bracket fixing screws must be fit central of glazing bar, mark up the centre line of the bar on to the undercladding if it is not clear by sight.




GENERAL NOTE ON BRACKET FIXING 2: Fitters tip - prep all of the brackets by BENDING to pitch before attaching to bars.


INSTALLATION - TRANSOM BRACKETS




Measurements are ALWAYS from the top edge of the PFTC fascia board when glazing is being inserted in to the bar.



Measurements are ALWAYS from the bottom edge of the steel bolster when solid panel is inserted into bar.




Using the location plan provided – see example above - find the dimension for setting out clip positions on the transom bars. Measure up the bar from top edge of fascia board, and mark it. If your roof features many transom bars, it may be simpler to cut a piece of timber to length and use as a template.



Using location plan provided, measure up and mark from bottom of steel bolster.




Take the transom bracket (CHA001 or CHAB001) and attach using two 4.2 x 19mm self drill Phillips pan head screws supplied- the back edge of the bracket should butt up to the pencil line.




Take the transom bracket supplied and attach using fixings provided.

INSTALLATION - STARTER BAR BRACKETS




On the starter bar, take a CHA001 or CHAB001 Transom bracket and snip off the ear (depending upon hand) if wall is plastered, further trimming maybe required.



Measure, mark and fit the trimmed down starter bracket using two 4.2 x 19mm self drill Phillips pan head screw.




If using a CHA001, snip off the ear (depending upon hand) if wall is plastered, further trimming may be required.




Measure, mark and fit the trimmed down starter bracket using two M4 x CHAA006 13mm self drill Phillips pan head screw.

INSTALLATION - HIP BRACKETS




Similar to step 16, seek the set out dimension from the location plan (12) for the Georgian or Victorian bar. Mark with a pencil line. Please note the dimension will be different from the transom bar. This graphic shows the left hand dimension being marked. Timber template to be held square to fascia board. Now mark right hand position.



Now attach using one of the two 4.2 x 19mm self drill Phillips pan head screws supplied – one screw curved top slot - do not 'nip up' at this stage, but allow bracket to pivot.




Having attached all the transom brackets, using a string line or straight edge mark across to each side of hip bar.



Now attach using one of the two M4 x 13mm self drill Phillips pan head screws supplied – one screw curved top slot - do not 'nip up' at this stage, but allow bracket to pivot.


INSTALLATION - TIE BAR BRACKETS (SOLID PANEL)




Take a CHA001 Transom Bracket and remove the 'ears' from both left and right as indicated (not required if using CHAB001). Drill additional holes as shown to allow access when in position.



Measure, mark and fit the bracket into position around the tie bar conduit as shown.




Where the roof is equal pitch across the hip, the bracket should sit as (a). On unequal pitches, the bracket may be skewed as in (b).




Where the roof is equal pitch across the hip, the bracket should sit as (a). On unequal pitches, the bracket may be skewed as in (b).


INSTALLATION - SPLAYED BAR BRACKETS



On a splayed bar – 7 and 8 on the sample location plan – measure and then strike a line across the face of the splayed bar's undercladding. Timber template to be held square to fascia board.



Using the location report, measure and mark both sides of splayed bar.




Take the transom bracket (CHAB011 or CHAB001) and attach using two 4.2 x 19mm self-drill Phillips pan head screws supplied- the back edge of the bracket should butt up to the pencil line.




now attach bracket CHA011 using one m4x13mm self drill Phillips wafer head screw - ensure screw is in centre line of bar.


GLASS PANEL BRACKET FOR ALL BAR TYPES (GLASS/SOLID INTERFACE)




Transom / Hip position




Gable position




Hip position



Close up detail




Typical Transom.




Typical Hip


INSTALLATION - CLOAKING PANEL CLIPS ON GLAZING BARS




Symbol '◻' shows if one support clip is needed central to the bar or one each adjacent to the bar - see steps 2 and 3 below.




Over the planked fascia board at the eaves, at each transom (but not tie bar locations) and splayed bar position, hook over the cloaking panel support clips CHA002. The brackets can be slid side to side along the eaves fascia board. FITTERS TIP: When fitting the modesty poly with the fitted LUVGS profile, it may be easier to slide the bracket to one side to allow more room and then slide back underneath once in position.



On starter bars, hip bars and transoms with tie bar brackets, a cloaking panel support clip is placed each side of the bar. The brackets can be slid side to side along the eaves fascia board. FITTERS TIP: When fitting the modesty poly with the fitted LUVGS profile, it may be easier to slide the bracket to one side to allow more room and then slide back underneath once in position.




IMPORTANT NOTE: If Super Duty eaves beam is used, then these are the cloaking panel clips (CHA015) that are supplied.




Fit the 16mm polycarbonate sheets to the corresponding LUVGS glazing support carriers, ensuring the polycarbonate flutes are perpendicular to the LUVGS. Refer to poly, LUVGS and PST offsets for positioning (page 32).


INSTALLATION - CLOAKING PANELS - EAVES




Now it is time to install the polycarbonate LUVGS assembly.




Before placing the polycarbonate-LUVGS assemblies, peel back one end of the glazing support tape protective film (ready to be pulled away when the sealed unit is finally in position).




If there is no LUVGS specified at a corner or valley corner due to tight jack rafters, cut a piece of BFG012-300 foam tape to size, remove the protective film and adhere it to the glass. Then fit the polycarbonate.



Place each polycarbonate-LUVGS assembly into its corresponding location: Sit the poly end on the support clips that are hooked over the fascia. Then push the LUVGS end up to the bars, resting it on the brackets. (Note: the brackets may need to be bent to allow this). If tight, slide eaves support brackets (step 31) to the side and then return after fitting modesty




Next bend back the bracket tabs to hold the LUVGS and polycarbonate in its final position. Pull LUVGS profile back against bar brackets and then pull loosened protective tape away from glazing support, pushing against the underside of the glass.




Bend back the tabs on the hip brackets – ensure the LUVGS is secured each side of the hip. Pull LUVGS profile back against bar brackets and then pull loosened protective tape away from glazing support, pushing against the underside of the glass.

INSTALLATION - RIDGE BOARD





Centre ridge board.




INSTALLATION - RIDGE - GLAZED PANELS

Product overview, completed ridge with glass panels

NOTE: NOTCHING REQUIRED TO BATTENS AROUND PVCU CLAD BOLSTERS - SEE PAGE 25.




Next take the pre-manufactured ridge board framework – ensure the board sits on the centre line of the ridge - struts. Use drywall screws. **NOTE: ENSURE INSULATION IS FITTED PRIOR TO FIXING RIDGE BOARD**




Next, fit battens around the ridge board. Line 25 X 44 battens with intersection of glazing bar and strut. **GENERAL NOTE: BATTENS ARE FIXED IN POSITIONS WHERE PLASTERBOARD CHANGES DIRECTION, ENABLING SCREWS TO BE FIXED TO THE EDGE OF THE PLASTERBOARD. BATTENS SUPPLIED IN PACKS, NEED TO BE CUT ON SITE TO SUIT.**




Attach timber battens at every strut position using dry wall screws. **BATTENS SUPPLIED IN PACKS, NEED TO BE CUT ON SITE TO SUIT.**



This is how battens should look round Georgian end (top) and Victorian end (bottom).




On the ridge end – where glazed panels are present – a second row of battens are needed. Measure down from the end of the steel bolster as shown.



Battens around the radius end will line through and remain parallel to the eaves.



Use an angle finder to determine angle of each hip bar.



Here is the general set out you will be working with (Victorian faceted end illustrated).




Transpose the angle onto the batten and create mitred cuts.



Using drywall screws, attach battens into steel bolsters/stub steel bolsters.


INSTALLATION - CLOAKING PANEL RIDGE



ASSEMBLE POLYCARBONATE SCREENS
Cut 25 X 44 battens and fit using double sided tape (LVGS001). Fit battens flush with front edge and 10mm back on each side.



Slot assembly into position.



IMPORTANT: POSITION CLOAKING PANEL ASSEMBLY INLINE WITH THE CROSS BATTEN (AS SHOWN) SCREW FIT INTO POSITION.




Fit LVCT600W and ensure it touches glass. Screw fit using drywall screws (along the lower edge).



Down each side of glazed area, attach a timber batten ensure it sits inline with bolster (see insert). Then as step 4, fit the LVCT 600W trim. Again ensure this touches the glass.



Fit LVCT trim - ensure it touches glass. Screw fit.



At eaves attach batten into steel bolsters using dry wall screws.



Next fit the 25mm insulation board, which is 590 x 2400mm. These boards must be laid at right angles to the glazing bars and run across the bars.




Fasten through the board and into the glazing bars using the drywall screw provided (3.5 x 50mm) and with a washer (kit of 25) behind the head to offer additional support to the board. Use location plan to identify board positions. Use tape LVFT045 - foil sealing tape - tape ALL joints of 25mm insulation.

PLASTERBOARDING & PLASTERING


IMPORTANT NOTE: Before applying 12.5mm foil backed plasterboard to ladder framework check lighting positions and adjust horizontal ladders to suit see p36 steps 12 and 13

PLASTERBOARDING SEQUENCE

- 1 Underside of pelmet (including mineral wool cavity)
- 2 Flat ceiling
- 3 Sloped ceiling
- 4 Vertical sides of pelmet



PLASTERBOARDING (DETAILS AROUND THE RIDGE)



DETAIL FOR CLADDING LIVEROOF HIPS WHICH HAVE A COMBINATION OF GLASS AND SOLID PANELS WITH SOME GLASS UNITS BOTH SIDES OF THE HIP.




UNBOLSTERED



BOLSTERED

TIE BAR ROSE FINISHING



Once 12.5mm plasterboard is fitted, the tie bar rose (CHA005) flexes over the PVCu conduit and should be spot bonded into position.

STOP BEAD ADJACENT TO GLASS PANELS




Ultraframe supplies a plasterers stop bead (CHA300) for the top edge adjacent to the glazing – ensure it is attached as shown. Be careful when handling/cutting this item not to damage the paint surface. Plasterboard finishes 20mm away from the glass.




Ridge end detailing


APPENDIX 1 - TIE BARS




APPENDIX 1 - INSTALLATION - FIT TIE BARS - TRADITIONAL TIE BAR




APPENDIX 1 - FITTING - TRADITIONAL TIE BAR




TIE BAR FOR GLAZING OR MIXED PANELS




APPENDIX 1 - FITTING TIE BEAM




Overview




Attach the threaded bar through the barrel and then fit washer and two M10 nuts. Next insert the barrel assembly into the slot in the underside of the glazing bar and secure with a further two M10 nuts.




Now insert the PVCu tube (this acts as a damper) over the threaded bar and secure in place with double sided tape or sealant. Now insert the box section beam over the threaded bar/tube assembly.



Now at the other end of the beam, add PVCu tube and the second barrel and repeat step 1. Swing the beam into position (as the overview at the start of this section). Adjust the threaded bar to length and then secure the barrel with 2 M10 bolts.




Now is the time to fit the claddings.




Ensure the asymmetric cladding is attached as shown – short side mates with the large slot whilst the long side mates with the small slot.

APPENDIX 2 - BOLSTER BARS - GLASS BOTH SIDES




PREFIX S: SOLID PANEL
PREFIX G: GLASS PANEL

STANDARD BRACKET BAR POSITION(s)	CHA001 (mm)	CHA003 (mm)	CHA090 (mm)	CHA11 (mm)	CHAA019L (mm)	CHAA019R (mm)
1	S-200					
2				G-207L/221R		
3				S-229L/256R		
4				G-264L/304R		
5	S-142	G-324L/357R			G-429	S-1822
6					G-418	
7	G-248	G-370L/371R				G-403
8	S-142				G-349L/335R	
9					G-329L/326R	
10, 14	G-325					
11, 15	G-325				G-349	
13, 16	G-325					G-349
17			G-276L/239R			
18	S-160					S-203
19	G-279					
20	S-160					S-203
21 - 23	S-160					
BOLSTER BRACKET BAR POSITION(s)	CHA009 (mm)	CHA012 (mm)	CHA013L (mm)	CHA011 (mm)	CHA013R (mm)	
12	G-424					




INSTALLATION - BOLSTER BARS - TRANSOMS




Using the location plan provided – see example in fig 1 - find the dimension for setting out bracket positions on the transom bars. Measure up the bar from the eaves beam, and mark the bolster cladding on all three sides. If your roof features many transom bars, it may be simpler to cut a piece of timber to length, to use as a template and mark using that.




Take the bracket CHAB013 and bend the bottom tab in the direction appropriate to the side of the bolster.




Line the bracket up with the datum line.



Now attach the bracket with a minimum of two CHA007 4.2 x 19mm self-drill panhead Phillips screws. Repeat the process for the other side bracket.




Then take the CHA009 transom bracket and line it through with the pre-marked minus offset dimension.




Attach with two CHA008 4.8 x 32mm self-drill panhead Phillips screws.


INSTALLATION - BOLSTER BARS - HIPS




Looking from underneath the bolstered Georgian hip bar, strike a line down the side of the bolster cladding and put a datum line on top of the fascia.




This is how it should look when you have marked each side of the eaves fascia with a datum point to measure from.




Now referring to the location plan, check the dimensions for left and right. Measure up the bar from the datum mark and mark both the side and face of the bolster cladding from the datum mark. Complete the task on left and right sides – the dimension may be different for each side.



This is how it should look once you have measured and marked the hip bolster cladding.




Take the bracket CHAB013 and line up with datum line (see step 6 to bend the bottom tab).




Now attach the bracket with a minimum of two CHA007 4.2 x 19 mm self drill panhead Phillips screws. Repeat the process for the opposite hand bracket.


INSTALLATION - BOLSTER BARS - SPAYED




From the location plan, find the dimension for the splayed bar and cut a piece of timber to that length. Hold the timber along the top edge of the PFTC fascia board and then against the glazing. Mark a line all the way round the splayed bar cladding.




Take the bracket CHAB013 and line up with offset line. Now attach the bracket with a minimum of two CHA007 4.2 x 19mm self-drill panhead Phillips screws. Repeat the process for the opposite hand bracket.




Then take the CHA012 splay bar bracket and line it up with the datum line – see illustration alongside. Fasten through centre hole with one CHA008 4.8 x 32mm self drill panhead Phillips screw.



Using the location plan, measure and mark either the positive offset or the minus offset.





Align feature on bracket to line.




Then take the CHA012 splay bar bracket and line it up with the datum line – see illustration alongside. Fasten through centre hole with one CHA008 4.8 x 32mm self drill panhead Phillips screw.


INSTALLATION - BOLSTER BARS




A cloaking panel (polycarbonate) support clip is placed each side of the transom bolster bars.



The support clips are located over the PFTC fascia board at hips and splayed bar positions too.




Fit the 16mm polycarbonate sheets to the corresponding LUVGS glazing support carriers, ensuring the polycarbonate flutes are perpendicular to the LUVGS. **Refer to poly, LUVGS and PST offsets (page 9).** Peel back one end of the tape protective film (ready to be pulled away when the sealed unit is in position).



Place each polycarbonate-LUVGS assembly into its corresponding location: Sit the poly end on the support clips that are hooked over the fascia. Then push the LUVGS end up to the bars.

INSTALLATION - BOLSTER BARS




Next bend back the tabs on the CHA013 to hold the polycarbonate and LUVGS in its final position.



This is how the transom bolster bar should look at this stage.



This is how the hip bolster bar should look at this stage.




IMPORTANT NOTE. NOW CHECK ON THE LOCATION PLAN WHETHER THE HORIZONTAL FRAME IS FOR 'ON FASCIA' FIXING OR 'BELOW FASCIA' FIXING – SEE MAIN GUIDE PAGE 17, STEPS 41 AND 42.


INSTALLATION - BOLSTER BARS




Having referred to the location plan, offer up the first horizontal ladder – a temporary timber support leg will help you here. Use 4.8 x 32mm at 250mm centres into pre punched holes to attach the ladder. Connect horizontal ladders together using two CHAA006 fixings. Add adjacent horizontal ladders.




Unpack the bolster corner infill – it is supplied flat and needs to be unpacked and folded into a right angle. Taped to it are two 100mm fixing channels – place these on one side for later. Offer up the corner infill and screw through horizontal ladder into the back of the corner infill – use two CHAA006 M4 x 13mm self drill wafer head Phillips screws per side of the corner.




Next take the CHA010 hip bracket assembly and fasten the 'V' shaped element into the corner infill using 4 CHAA006 M4 x 13mm self drill wafer head Phillips screws.



Now, screw up through the horizontal ladders to complete the assembly of the CHA010 hip bracket assembly using two CHAA008 4.8 x 32mm self drill panhead Phillips screws. Ensure horizontal ladders are level.




Using the location plan, choose the matching vertical ladder and offer it into position – hold firmly whilst attaching to the matching horizontal ladder using M4 x 13mm fixing, at 250mm centres into pre punched holes. Ensure the vertical ladder is behind the brackets.




Butt the vertical ladder into the side of the corner infill – secure using two CHAA006 M4 x 13mm self drill wafer head Phillips screws. Use two per vertical ladder.

INSTALLATION - BOLSTER BARS




Secure the CHAA009 bolster transom bracket at each side to the vertical ladder using CHAA006 M4 x 13mm self drill panhead Phillips screw.



This is what the final transom bar should look like.

APPENDIX 3 - BOX GUTTER INSTALLATION



Box gutter foam to be cut back 70mm* to enable the box gutter to sit flush on the frames.

Apply a continuous bead of appropriate sealant to the front and inner legs of the window frames. Lift insulated box gutter into position – ensure it has adequate support whilst fitting.

* May be less than 70mm – measure frame and reduce cut back if necessary.



Place eaves beam section – with under gutter trim attached – onto the side frames. Seal the joint between the eaves beam and box gutter


NOTE: IF FITTING CORNICE, REMOVE THE UNDER GUTTER TRIM.




Whilst ensuring that its level, drill through the back edge of the aluminium at 600mm centres. Bolt to the house wall using masonry anchors that are suitable for the substrate (not supplied).




Either peel back or knife off a small amount of the insulation where the cleat is to be fixed. Drill a 4.5mm pilot hole and then fix the cleats with the two M5 12mm taprite screws provided. The protruding taprite screws will need trimming back prior to fixing the adaptor (alternatively, when its time to insert the adaptor, undue the taprites, drill a pilot hole through the adaptor and then re-screw the taprites and fully seal).



Mark out and grind a channel in the masonry for the flashing – blow out any dust in the channel.



Now seal the internal joint between the eaves beam and box gutter and back point the leading edge of the box gutter where it sits on the side frames. Knife off a small section of the undergutter trim in preparation for the insertion of the adaptor.



Now, from the bag in which the adaptor is supplied, take the special tube of sealant, Gutterbond. Thoroughly clean the internal surface using wire wool and a degreasing wipe to ensure clean and grease free. Apply a generous bead of it evenly across the mouth of the box gutter, 20mm back from the front edge.



Slide the adaptor into the aluminium box gutter, raising up its front edge to utilise the unique 'snow plough' effect. This spreads the Gutterbond evenly under the adaptor. Push the adaptor firmly up to its end stop, so that it will line through with the Classic gutter attached to the eaves beam.




With the adaptor tight to the end stop, turn the toggles upwards to firmly press the adaptor into the Gutterbond.


APPENDIX 3 - BOX GUTTER INSTALLATION




Use the balance of the Gutterbond to back point any gaps at the front edge.




Seal the top and bottom edges of the aluminium box gutter, where it abuts the house wall.



Lastly locate the upper legs of the fascia board on to the box gutter. Finally seal the undercladding against the house wall.




APPENDIX 3 - BOX GUTTER JOINTING



Thoroughly clean the mating parts using wire wool. Surfaces must be clean and grease free. Apply a generous bead of low modulus neutral cure to the pre-fixed internal sleeve along the entire face of the sleeve.




Drill through the top edge of the aluminium box gutter at 600mm centres. A fixing must be positioned within 50mm each side of the joint. Offer second half of the box gutter up to the internal sleeve and push firmly on. Fasten this second box gutter run to the host wall with masonry anchors suitable to the substrate. Ensure both sections are level and flush.



Drill 6.5mm holes through the box gutter and sleeve (at positions shown, ensuring both halves of the box gutter are flush together) and fix using the bolts, nuts and washers provided and in the order shown. Trim any excess off the bolt head before fitting the internal cladding as it may foul.



Check surfaces are dry, clean and grease free. De-grease if necessary. Heat both the sealing tape and the box gutter with a heat gun and position the tape over the joint. Press the tape firmly across the joint of the sleeve and the box gutter ensuring there are no air pockets.




Now seal over all the exposed bolt heads, on the inside and outside of the box gutter.

ALL box gutters (especially those with tie bars or joints) **MUST** be supported.

Ultraframe recommends several types of support for box gutters including brick piers. Fitting a conservatory box gutter without adequate support will lead to structural failure. Please take the correct steps **BEFORE** installation.

REINFORCED BOX GUTTER INSTALLATION

(USE IN CONJUNCTION WITH STANDARD GUTTER INSTALLATION STEPS)



PRE-CHECKS / ADVICE

Box gutter weight is approximately 13kg/m. A 6m box gutter will weigh approximately 78kg. You may consider using lift equipment such as a genie lift or similar.

If fixing to a bungalow soffit, we recommend checking behind the fascia to ensure that there is a suitable substrate to fix to.

Check the roof tile overhang (minimum of 50mm) to ensure it will not foul on the gutter reinforcement. If so either pack off (affecting the roof size) or reduce tile overhang.

SUPPORTS




When using the reinforced box gutter, it **MUST be supported at each end by either hup walling, a brick pier, or a post (by 100mm minimum).** When the overall length is greater than 6m and a split is required, the box gutter **MUST** be supported by at least 100mm either side of the joint.


If you would like to use a post as a support, please contact Ultraframe.



Lift the box gutter into position, taking into consideration the weight.



Whilst still supported, pull gutter away from the wall for access and grind a channel in the masonry for flashing. Blow out any dust in the channel.



Lift gutter slightly to cut back foam insulation to enable the box gutter to sit flush on the supports.


Apply a continuous bead of appropriate sealant to the front and inner of the supports. Lower the insulated box gutter into position – ensure it has adequate support whilst fitting.



If required, place eaves beam section – with under gutter trim attached onto the side frames. Seal the joint between the eaves beam and box gutter.




Ensuring the box gutter is level, fix back into the host wall through each gap in the I-beam and at both ends of the gutter using appropriate anchor fixings for the substrate. Dependant on access, a socket wrench may be used to reach behind the reinforcement.



If fitting to a bungalow soffit, ensure that box gutter is fixed along its length into a suitable timber batten behind fascia board using appropriate fixings. When installing a box gutter on a soffit, ensure the soffit is insulated to avoid condensation

APPENDIX 3 - BOX GUTTER SUPPORT



BOX GUTTER STRAP

165mm box gutters

These are supplied loose and MUST BE FITTED – they are a structural requirement of the roof. The straps must be installed within 75mm of glazing bar centres (when measured from centre of the strap to the centre of the bar). To install these straps, simply ‘nip up’ as shown.

265mm/special box gutters

Straps are factory welded into position.



BOX GUTTER HANGER

165mm box gutters

If these have been specified by your company at the time of order they are supplied loose and must be fitted.

The structural requirement for the hanging brackets are 2 x hanging brackets (sat side by side) at a maximum span of 2300mm unless the roof has a tie bar or joint on the boxgutter which should then be positioned in the same area.

Drill through the head of the hanger into the centre of the masonry, avoiding the mortar joint if possible. Use a masonry anchor suitable for the substrate. Lead flashing should be dressed down over the hanger, and snipped around the sloped leg. To attach it to the box gutter, simply ‘nip up’ as shown.

265mm box gutters

Hanger not available.



GALLONS BRACKET



These are available for 165/265mm box gutters.

To install, notch out the insulation to ensure metal to metal contact between the extruded box gutter and gallows bracket. Offer up the gallows bracket and mark it ready to drill – always try to line up with the centre of a brick rather than a mortar joint. **Drill the gallows bracket and fix using three masonry anchors that are appropriate to the substrate.** Finally, notch out the undercladding, offer it into position and clip in.

Maximum centres are 2300mm. If the roof has a tie bar installed or a joint within the box gutter, then a gallows a gallows bracket should be installed directly underneath it.



APPENDIX 3 - RAISED BACK BOX GUTTERS



90° eaves and raised back box gutter assembly

Seal the top and bottom edges of the box gutter and follow all other steps as per standard box gutters on page 54-55. When installing the lead flashing, ensure that the top of the flashing is higher than the point of rain water discharge from the glazing bars. Clad off the deep skirt of the raised back box gutter using multi-board (not supplied).

Place the inline strap (SES005, 165mm / SES006, 265mm) over the single roofing bolt on the sloped gutter. Temporarily fix the bracket to the host wall using three M8 sleeve anchor bolts (SAB001) supplied. Fit the starter bar. Secure the strap to the eaves with the two fixings supplied (UZBGF001-D). Finally, fix anchor bolts.





Following steps for the installation of box gutters on pages 59-62, check that the roofing bolts are in position (i.e top and bottom of the slope)

Place the short lengths of furring top cap and modified starter bar on to the two bolts. Please note that the bolts should be staggered, one each side of the bar.

Lift the ‘L’ shaped sealed unit into position and carefully position. Your office may have not ordered an ‘L’ shaped unit but may have split the unit into two, use a muntin bar to joint them (see page 34 of the Classic Install Guide for details of muntin bars).

APPENDIX 3 - RAISED BACK BOXGUTTERS



Offer the raised back or special box gutter into position. Carefully mark onto the aluminium leg against the host wall the position of each fixing – **use 600mm maximum centres using masonry anchors that are appropriate to the substrate (not supplied).**

Lift the box gutter down to the ground and turn it around. Drill through the aluminium leg (that abuts the host wall) at the pre-marked positions. Whilst the box gutter is on the ground, seal along the front/rear face where the deep skirt sits inside the head of the extruded box gutter.

Lift the box gutter back into position, check levels, and then mark the wall (through the pre-drilled holes) ready to drill the host wall and grind out for the flashing.




Knock down the glazing bar top cap so it finished flush with the bottom of the bar.


Two end caps are provided, one left hand and one right hand. Cut the end cap across its width so that it fits snugly to the face of the glass, remove it and then using the correct sealant, refit.

Internally, cloak off the open end of the glazing bar by fabricating a small end closure – seal into place. Fit the lower fascia and box gutter claddings in the usual way. Scribe and secure the upper claddings to the factory applied horizontal sticky tape strips. (For raised back box gutters beyond 300mm in height, vertical claddings must be fabricated from your own supplied multi-board).

APPENDIX 3 - RAISED BACK BOX GUTTER - INTERNAL PELMET



SOLID CROSS SECTION SHOWN FOR REFERENCE




GLAZED CROSS SECTION SHOWN FOR REFERENCE.



If the area around the box gutter is glazed fit brackets in marked positions on the bars as per standard installation.




Fit the polycarbonate modesty panels and bend over bracket legs to secure.




If the area around the box gutter is solid, use location plan provided to measure up and mark from the bottom of the steel bolster.



Take the transom bracket supplied and attach using the fixings provided.



If the area around the box gutter is solid, additional insulation will be specified.
Fit 90mm insulation block to front face of the internal box gutter fascia with sealant- this will help to prevent cold bridging.




Assemble matching vertical and horizontal frames- use fixings at 250mm centres into pre-punched holes. Ladders will have different heights depending on whether adjacent panels are glazed or solid.



Offer up into position and fit in place using CHAA006 (bag of 25).

APPENDIX 3 - RAISED BACK BOX GUTTERS



In solid areas, fit 25mm insulation beneath the gutter- offer up the back edge into the rear insulated internal pelmet channel first, then pivot up and slide into position, engaging with the front insulated internal pelmet channel to secure.




In the case of an L-shaped conservatory, where the box gutter returns around the house wall If the distance between the side gutter fascia and the adjacent transom bar is less than 100mm, 90mm insulation will not be specified and a gap will remain- in this case, insert mineral wool to fill the cavity.



Fit 25mm insulation adjacent/beneath gutter around the return as shown in step (10) to help prevent cold bridging. Remember to fully insulate the entire internal pelmet with mineral wool supplied.


APPENDIX 4 - VALLEY INSTALLATION - EXTERNAL



For exact half ridge location, please check as above.



Assemble as much of the main Georgian (or vic) roof side of the 'P' shape as possible. CHECK THE PITCH. Ensure the full ridge is level. Separate the two part half ridge. REMOVE THE RAIN BAFFLE UPPER LEG. Fit the back section of the half ridge in position, level across the PVCu top carriages (as shown), then secure to the host wall with anchor bolts suitable for the substrate. The first anchor to be 50mm away from full ridge, the second 250mm and then at max 600mm centres.



Re-assemble the two parts of the half ridge, ensuring that the front carriage is located in the one of six possible positions. To do this make sure that the original screw holes for the self tapping screws line up. Ensure the profile is fully engaged along its length. Use screws provided at pre-set centres to attach the two parts of the half ridge.




Next, pick up the aluminium valley section, ensuring the under cladding location bars are slid into position. Then, offer the valley up to the roof and locate onto the captivated bolts in the ridge, half ridge and eaves beam. Tighten the four nuts holding the valley in place.



Re-fit the half ridge rain baffle. NOTE: If glazing with 24mm glass units or 25mm polycarbonate, the rain baffle upper leg needs to be set in the highest position.


APPENDIX 4 - VALLEY INSTALLATION




Re-fit the glazing support trim, where the valley meets the eaves beam.




Now run a continuous bead of suitable sealant down the entire length of the aluminium valley profile, at the point of the hinged connector in the centre.




Using the location plan provided, assemble the various glazing bars onto the valley. Use the washers and nuts provided to ensure a robust joint is created.




Fit the double sided sealing tape to each of the valley wings. Tease one end of the protective tape loose, crease it about 50mm in from the end and fold over ready to extract once the glazing panels are laid in position.




Each glazed or solid roof panel on a valley should be fitted with 2 x wire clips to hold it in position. Insert the clips through the precut slots within 100mm of each end of the glazing end profile as shown.



The hooked 'ears' should locate behind the protruding aluminium lip detail as shown. Fit to the panel and apply a continuous bead of relevant sealant (MS polymer on self cleaning glass). Slide into position on unit and wipe clean any sealant from surface. (Sealant position indicated in RED).



Place the panel in its correct position (refer to location plan if in doubt). Position the end profile down into the valley as shown. With the glazing pressed flat against the valley profile and your fingers underneath, pull the panel up into the rain baffle and allow the clip to 'spring' into position and 'lock' the glazing in place. Once properly fitted, the clip should lock into place as shown (inset).



Fit the valley end cap using the two plastic rivets supplied.





The joint between the full and half ridge PVCu top caps is sealed by the use of a capping connector. This needs to be trimmed to suit. Bed the capping on suitable sealant and fix using the plastic rivets provided.


APPENDIX 4 - VALLEY INSTALLATION - INTERNAL - SOLID




Insert mineral wool (LVR001) between the valley wings along the whole length to insulate the cavity.




Fix valley plate (LVP300) to underside of plastic spacers at 250mm centres.




Position and fit polystyrene valley insulation where shown using sealant to secure.



It may be useful to fit an angled batten at the host wall – this will provide a positive fixing point when fitting the plasterboard.



Insert mineral wool along the length of the wallplate.



Fit 90mm insulation and fill voids in jack rafter positions with mineral wool to minimise potential for cold bridging.



Now fit the internal pelmet. The valley bracket should be anchored to the valley plate as shown.



Fit a length of timber batten to the host wall, ensuring that its underside lines through with the underside of the struts (LVT001/LVT002). This will provide a fixing point for the ridge board fitted in the next step.



Fit the ridge board as described on page 39.

APPENDIX 4 - VALLEY INSTALLATION - INTERNAL - SOLID



Fit the ridge battens, as described on page 39.
NOTE: On the valley side, the batten should terminate on the valley Plate centreline as shown.



When fitted, the 25mm insulation should butt up to the batten, and the plasterboard should fix through into the underside of the batten as shown.



Now fit the plasterboard – the detail where the valley abuts the host wall should look as shown.


APPENDIX 4 - VALLEY INSTALLATION - GLAZED



Mark out and cut the valley cladding and fix valley fixing plate by following steps 1 - 5.




Using a level, plumb up off the horizontal frame and mark the outer bottom edge of the valley cladding on both sides (Mark "A").




Using an angle finder (or joiners bevel). Draw a line on the valley cladding from the mark 'A' parallel to the eaves.


APPENDIX 4 - VALLEY INSTALLATION - INTERNAL - GLAZED



Cut a 200mm length of valley undercladding. This will act as a template for the bottom scribe. Use a 'straight edge' placed tight to the eaves fascia, then mark and cut.




Measure dimension A then add B for overall length. Mark and cut the claddings for both left and right side. Push fit the claddings into position.



Valley claddings shown in situ at the eaves.



Valley claddings shown in situ where the valley meets the ridge.



NOTE: The transom bracket CHA001 MUST be trimmed and adapted to suit situations where a transom bar, valley and insulated internal pelmet vertical frame intercept, as shown above.



Temporarily position the valley fixing plate central of the valley with the top edges touching the marked lines. Mark either side of the plate (shown as 'B' on the cladding). Now remove valley fixing bracket.




Then measure 105mm in from each side of the valley cladding and extend mark B top and bottom to form pencil rectangle. Cut out valley cladding.



Attach the appropriate polycarbonate-LUVGS panels and fit as shown in the main internal insulated pelmet installation guide. (page 4).

APPENDIX 4 - VALLEY INSTALLATION - GLAZED



Fit the valley corner infill panel to the horizontal frame, level up and secure to the valley plate.



FIT THE STRAP CHA018 USING M4x13 SELF DRILL SCREWS, to the valley corner infill panel and the valley fixing bracket. It may be necessary to bend CHA008 to suit.



Fit the vertical frames. Fix the frames into the valley corner infill and the horizontal frames.




Fit valley plate at top of valley using fixings at max 250mm centres.



Fit modesty panels adjacent to valley – create cassette assembly as shown using double sided tape to fix battens to the polycarbonate and screw fix the support batten into position as shown. Offer up the modesty panel into position to define the position of the support battens.




Offer up the cassette assembly into position.



Each of the 4 modesty panels immediately next to the valley, to its left and right, has a different make-up to ensure adequate fixing. Particular attention needs to be paid to ensuring that battens terminate at the centrelines of the steel undercladding so that adjacent panels can 'share' these anchor points. Battens approaching the valley itself can be screwed to the valley plate fixed to its underside. Ensure that the polycarbonate and attached battens are set back 6mm from the support battens to allow space for fitting the multiboard trim




Fix into position using plasterboard screws. NOTE: when fitted, the battens should terminate at the centreline of the steel undercladding to allow for fitting of the adjacent panels



Fit adjacent panels by the same method as previous step. Again, terminating the battens at the centreline of the steel undercladding to allow the fixing of adjacent battens in the following steps. (Detail at wall plate shown)

APPENDIX 4 - VALLEY INSTALLATION - GLAZED



Detail at ridge shown.



Fit a length of timber batten to the host wall, ensuring that its underside lines through with the underside of the struts (LVTS001/LVTS002). This will provide a fixing point for the ridge board fitted in the next step.





Fit the ridge board as described on page 39.



Fit second row of battens as described on page 40.



Fit additional battens where glazing is present along the host wall as shown.



Slide remaining modesty panels into position, ensure that the batten on the screen is set 6mm back and screw fix to secure.




Fit 25mm insulation.




Now fit the plasterboard – the detail where the valley abuts the host wall should look as shown.

Fitters tip: fit the small triangular segment of plasterboard shown first, allowing space for the upper adjacent board to slide in above it, as there will be nothing to screw to at this point.




Where plasterboard intersects with the valley undercladding it should be notched to fit and fitted with LVPT250/1 PVCu plasterboard trim.

APPENDIX 5 - VENTILATED WALL PLATE




The aluminium wall plate body has been cut to length to extend 45mm beyond the side frames of the conservatory. Slide the aluminium carriages supplied with the wall plate onto the main body and space out at approx. 500mm centres.

NOTE: ROOFS WITH A PITCH OF 15° AND OVER SEE STEP 9



Offer the wallplate up to the wall – the height to the underside of the wallplate from the underside of the eaves (see above) can be found in the insulated internal pelmet setout plan paperwork.




Drill through the wallplate main body and directly through each carriage to suit the masonry anchors being used (not supplied). Mark the position of each masonry anchor on the house wall and drill the house wall to suit.


APPENDIX 5 - VENTILATED WALL PLATE



If the pitch of the roof is greater than 15° then the wall plate is supplied with a number of aluminium packers. These packers hook onto the back of each carriage and act as a wedge between the carriage and the house wall. These should be fitted when drilling and fixing the wall plate. The packers may be used in multiples and each packer will tilt the wall plate by 5°. When packers are used it will be necessary to ease the wall plate top capping back to the wall and secure with plugs and screws before dressing the lead flashing over the top capping.




When insulating, ensure that the cavity underneath the ridge is filled with mineral wool insulation (supplied).



Make sure the appropriate number of roofing bolts are located in the bolt slot of the wall plate before finally fixing the wall plate to the wall.




Systematically install the masonry anchors at 500mm centres (Not supplied).



Fit the back and main baffle. (It is pre-cut to the external frame dimension - DO NOT CUT).

APPENDIX 5 - HALF RIDGE INSTALLATION



The weathering shield must be cut through the marked line. Note the illustrations shows the cut required for a left hand hipped end.

SEE p19 for further guidance on trimming the weathering shield to suit glazing thickness/bar positions.




Prior to attaching the starter bar to the mounted starter bar bracket, remove the M6 taprite screw. Locate the bar on to the bracket and on to the single bolt placed in the eaves beam, re-insert the screw.




Check the half ridge for being level and then check the starter bar pitch. Drill and fix the die cast back plate to the host wall (avoiding mortar joints) using an anchor bolt suitable for the substrate. Drill and fix the starter bars(s).




Attach undercladding, having first sub assembled the ventilation button (separate installation leaflet provided in vent button kit)



Cut the PVCu wall plate top capping to the overall width of the conservatory (externally) and notch over the top of the lean-to cloaking trim at each end. Push fit the wall plate top capping.




Trim the wall plate end caps and fit using sealant appropriate to the glazing. Fit lead flashing.



Chase out and install the lead flashing. Add the pre-cut weathering shields. Seal the weathering shield to the host wall.






Glaze the roof. Fit and seal the top of the glazing bar top cappings. Install the ready assembled half ridge top capping and external radius end. Finally install the lead flashing to suit.



When insulating, ensure that the cavity underneath the ridge is filled with mineral wool insulation (supplied).

APPENDIX 6 - GABLE INSTALLATION


BEAM



Trial fit the gable beam and the eaves beam ensuring the inside face is flush with the inside face of the window/door frames. Remove, then apply a continuous bead of sealant to both the front and rear edges of the window/door frames. Seal the gable beam to the frames


Fit the under gutter trim to each section of eaves beam and gable beam, position the beams and slide the corner cleats (already attached to the eaves beam) into the gable beam. Drill through the holes already in the gable beam into the eaves beam. Fit the 90 degree external gutter corners to the gable beam length of gutter. The brackets are at maximum 750mm centres and 200mm from each corner.

NOTE: IF FITTING CORNICE, REMOVE THE UNDER GUTTER TRIM.



Roof Pitch (°)	Dim A (mm)
10	83
15	85
20	87
25	89
30	93
35	98
40	104



With the guttering in place, trim the gable beam top cladding. The cladding is supplied over length and cut to suit the roof pitch (see table).



Next attach the notched gable beam top cladding on to the head of the gable beam.

APPENDIX 6 - GABLE INSTALLATION - DUO PITCH


FRAME




Position the gable window frame central to the gable beam (A), and mark the position. Remove the frame and again run two beads of sealant along the head of the gable beam top cladding (the width of the window frame only). Replace the frame centrally and back against the upstand of the gable beam top cladding. Fix securely through the head of the gable beam (B) with self tapping screws (not supplied).

Mark and cut the gable infill end cap (C). Notch inner bottom edge to allow the end cap to sit flush and tight to the gable window frame. Trim top edge to suit pitch of roof and gable frame firing top cap which should be placed into position for marketing purposes. First sealant and then screw the end cap to the gable frame.

Trial fit the gable infill wedge (D). Remove, run two beads of sealant and place back in position, tight up against the infill wedge end cap. NOTE: it will be necessary for non standard pitches to trim the infill wedge to suit the pitch, maintaining the 135mm height dimensions.




Seal the firing top cap to the firing and to the glazing bar above



Cut the 'H' sections, mitring where necessary for a neat flush appearance (E). Fit these and the apex wedge (F) using continuous beads of sealant. NOTE: it will be necessary for non standard pitches to trim the apex wedge for a correct fit



Fit the hollow core beams into position on top of the 'H' section (G). Screw up through the window frames as shown to secure.



APPENDIX 6 - GABLE INSTALLATION - DUO PITCH



Position the beam top cap (H) along the furring. The bottom edge of the cap should be cut to finish flush with the gable beam. The top edge should be square cut to terminate at the horizontal beam cut, as shown.




Place and support the ridge, ensuring it is central to the gable frame.



Place the starter bars onto the beam top caps and secure to the ridge and eaves beam. Securely fix the starter bars to the beam - screw through at an angle as illustrated to ensure a solid fixing into the aluminium reinforcement.



Once the panels are in place, fit the starter bar top caps into position.



Take the Gable end cap - Create notch as shown to fit around the beam and seal the ridge body as shown.




Using plastic pop rivets supplied, drill as shown and install rivets - avoid 'flat top' of profile.

APPENDIX 6 - GABLE INSTALLATION

- LEAN-TO (10.1° AND ABOVE)



The gable beam will be pre-fitted with a structural moulding. This has three fixing points to allow attachment to masonry- choose holes that align with solid masonry and attach using resin anchors suitable for the substrate/ loads. When fitting the gable beam cladding, it will be necessary to trim a small section at the host wall as shown to allow it to sit over the structural moulding (fixings not supplied).



Note: In certain cases, where custom frames are specified, the lower wedge (D) will have to be fabricated on site.

NOTE: THE WALL PLATE MUST BE FITTED BEFORE FITTING THE GABLE FRAME



Align window frame with host wall (A) and follow steps(1-5) on page (70).




Fit hollow core beam- screw up through window frames as shown, then fit the furring top cap using appropriate sealant.



Securely fix the starter bars to the gable furring -screw through at an angle as illustrated to ensure a solid fixing into the aluminium reinforcement.



Scribe and cut the bottom end of the cloaking trim horizontally for a flush fit on the gable beam.



Offer the cloaking trim up to the side of the gable ridge cap and scribe to suit the roof pitch -push into place against the end cap.




Finally, fit the starter bar end cap.



Fit starter bar claddings, cloaking panels and half ridge top cap (if applicable to your choice of ridge). Scribe half ridge end cap to fit into 'shoulder' of cloaking panel and fit using sealant.




When plasterboarding the internal it may be useful to fit an angled batten at the host wall - this will provide a positive fixing point when fitting the plasterboard.



When fitted, the 25mm insulation should butt up to the batten, and the plasterboard should fix through into the underside of the batten and terminate at the host wall as shown.

APPENDIX 6 - GABLE INSTALLATION

- LEAN-TO (10.09° AND BELOW) - EXTERNAL



On lean-to's of 10.09° or below, a solid furring will be specified. This will be supplied over-length and will require cutting to size on site.

	Half Ridge		Variable Ridge		Parabolic Ridge	
Roof Pitch	Dim A (mm)	Dim B (mm)	Dim A (mm)	Dim B (mm)	Dim A (mm)	Dim B (mm)
5	97	11	67	10	59	23
6	97	11	67	10	59	24
7	97	11	67	10	59	25
8	97	11	67	10	59	25
9	97	11	67	10	59	26
10	93	11	68	10	59	27



With the wall plate pre-fitted, offer up the furring into position- pushing it up against the upstand on the gable beam cladding.




Screw up through the pre-drilled holes in the gable beam at 400mm intervals to secure the furring firmly in place. Use screw pack LVFF010 (supplied).




Notch the furring cover and top cap to fit round the ridge body as shown. Fit into place with continuous beads of sealant.

Fit starter bar and top caps as described on page 67. Screw through starter bar into furring to stabilise.



To complete the exterior scribe the end cap to fit over 'shoulder' of the cloaking panel.



Fitters tip: The notch created in the furring (see above) will leave a visible gap on the exterior under the cloaking panel- if the furring is grey, the offcut from the end cap (trimmed in the previous step) can be used to create a 'patch' to cover the gap.

APPENDIX 6 - GABLE INSTALLATION


- LEAN-TO (BELOW 10°) - SOLID - INTERNAL



If the roof panel adjacent to the furring is SOLID - After fitting 90mm insulation, screw fit CHA405/1 channel where the 90mm insulation converges with the inside face of the furring this serves to carry the edge of the 25mm insulation and offers a surface to screw the plasterboard to. The channel should span between the host wall and the internal pelmet frame.



Fit the 25mm insulation and plasterboard to the ceiling before continuing to the next step.



Fit MTB004 packer (with LVGS double sided tape each side) where the plasterboard converges with the inside face of the furring this will create a level surface to fit the timber frame created in the next step.

APPENDIX 6 - GABLE INSTALLATION

- LEAN-TO (BELOW 10°) - GLAZED - INTERNAL




Fit the frame into position against the furring, fill the cavities with 25mm insulation and finish with plasterboard.




If the roof panel adjacent to the furring is glazed- In order to fit the cloaking panels (as described on page 41) you will need to screw fit a length of CHA405/1 channel to the furring to carry the timber battens and 25mm insulation - this will also provide a surface to screw up through when fitting the plasterboard.




Fit the 25mm insulation into place between the battens and into the steel channel.



Fit black multiboard into position against modesty panel. Ensure it touches the glass and fix using drywall screws.




Fit a 13mm x 44mm batten along the furring between multiboard and insulated internal pelmet frame as shown. Push the batten up to the underside of the furring top cap (see inset). Also, fit upright timbers above eaves fascia at 600mm centres. Stack a 19mm x 44mm batten of equal length on top of the 13mm horizontal batten and screw through to secure.



APPENDIX 6 - GABLE INSTALLATION - LEAN-TO (BELOW 10°) - GLAZED - INTERNAL




Slide LFS600 black plastic trim into place between the glass and timber battens as shown. This creates a solid black detail when viewed from the outside.



Section view of LFS600 trim and timber batten positioning.



Fit LVCT600 trim, covering timbers and enclosing LFS600 black plastic trim- again, ensure it touches the glass and fix using drywall screws.



Section view of LVCT 600 trim positioning.



Add a framework of 25mm x 44mm battens this should consist of 1 horizontal batten along the lower edge of the eaves fascia and uprights stacked on top of the 13mm verticals installed in step 15.



Fill the cavities between the timbers with 25mm insulation and finish with plasterboard.

APPENDIX 6 - GABLE INSTALLATION - INSULATED INTERNAL PELMET - SOLID




In solid situations- line gable bracket CHAB019 through with bracket on adjacent bar and push up into 90mm insulation. Screw through gable using CHA008 self drill screws.



Fix the vertical frame into the fascia board using 2 x CHAA006 (M4 x 13mm) self drill Phillips, wafer head screws (supplied).




Now fit living room channel to gable- this is used to carry 25mm insulation and to secure timber battens and plasterboard adjacent to the gable.



where panel adjacent to the gable is solid - the channel spans from insulated internal pelmet frame up to ridge detail and should be fitted directly below the 90mm insulation (insulated internal pelmet detail shown).




Duo-pitch ridge detail shown - channel terminates at ridge board.




Mono pitch detail shown - channel terminates at host wall.

APPENDIX 6 - GABLE INSTALLATION - LEAN-TO FULL HEIGHT WALL BOUNDARY CONDITION





Gable support beam sits on full height wall / cill, no gutter returns.



Gable support beam sits on full height wall / cill, no gutter returns.


APPENDIX 6 - GABLE INSTALLATION - INSULATED INTERNAL PELMET - SOLID



In glazed situations - see location plan for G dimension and set bracket shoulder 20mm below glazing. Screw through gable using CHA008 self drill screws.




Close up detail - N.B. the bracket MUST be set 20mm below the glazing line as shown.



Referring to the location plan, place the polycarbonate-LUVGS assembly into its corresponding locations: Mark and notch the corner of poly carbonate as demonstrated.



Where panel adjacent to the gable is glazed, only a small section of the channel is required at the ridge- this should line through with the underside and front of adjacent stub steels (duo pitch detail shown).



Mono-pitch detail shown- if adjacent steel is full length the offset distance from the top of the steel is 350mm.


APPENDIX 7 - MUNTIN (GLASS JOINTER)

Aluminium Muntin Bar



Take the muntin bar profile (top and bottom section) that matches its corresponding sealed unit. Take the lower PVCu section and allow it to span between the two adjacent glazing bars. Lower into position the up slope sealed unit. NOTE: MUNTIN SHOULD BE SAME WIDTH AS UNIT.


Now take the upper aluminium section and lay it face down onto a smooth clean surface to protect its painted finish. Using the relevant sealant (MS Polymer sealant such as Rotabond 2000 must be used on self cleaning glass), apply a generous bead to each side.



Now lift the sealed unit that goes on the lower slope into position, turn the upper profile over, place it into position and tap down the profile using a non marking plastic mallet. Wipe clean any sealant from the unit face. NOTE: WE RECOMMEND A SECOND PERSON TO SUPPORT THE MUNTIN FROM THE UNDERSIDE WHEN TAPPING DOWN.


Now, tap the glazing top cap into position, which will 'trap' the muntin profiles.

Removing The Glazing Bar Top Caps



Slide the end cap up and off the fixing block and unscrew the fixing at the end of the glazing bar and then lift with force to 'pop' capping off (reverse steps 50-52 on p20). There are 2 methods to release the top cap. Slide the glazing bar top cap down or alternatively, insert a broad flat head screw driver into the gap above the aluminium barbs and 'pop' top cap and using hands lift capping free of clips. One or more clips - LVCC001 - may be damaged during the process, spares are sent with each roof.

Aluminium Glazing End Closure




Take the painted profile and protect its surface. Apply a bead of relevant sealant (MS polymer on self cleaning glass). Slide into position on sealed unit, wipe clean any sealant from surface of glass.


APPENDIX 8 - ALTERNATIVE RIDGE BOARD DETAIL



It may be desirable to create a 'box' detail under the ridge board to facilitate the inclusion of downlights etc. Note: Ultraframe does not supply an off the shelf solution for this detail.



Construct a timber framework with cross members positioned where appropriate for adequate fixing of your chosen cladding (plasterboard, plywood etc.)



Fix the timber into position using screws of sufficient length to pass through ridge board and into the struts, as shown.



Clad the box with the preferred material (plasterboard, plywood etc.) and finish with a decorative timber edge moulding

APPENDIX 9 - GLAZING BAR TOP CAP REMOVAL



NOTE: If present - it may be necessary to remove the top section of the cornice to obtain proper access for top cap removal.
Remove the screw attaching the top cap to the bar. Grip the top cap firmly and pull down the bar by approximately 150mm.




On long bars, friction may prevent the cap from sliding down the bar. In this case, push a long screw driver under the top cap and pull upwards to release the lower section.




Using 2 hands, pull the top cap upwards sharply to disengage the top cap clips and remove.
NOTE: top cap clips are likely to be damaged when removing caps – these will need to be replaced.

APPENDIX 10 - CLEANING AND MAINTENANCE




If surface damage is encountered, use 120-360 grit paper to prepare the surface. Wipe clean with white spirit.




Ensure the surface is dry – apply a thin primer coat using a fine brush.



Finally, apply an air drying top coat with a fine brush.



General cleaning can be undertaken by a wash with warm soapy water.



For added protection, a wax polish can be applied up to twice per year – follow the polish manufacturer's instructions carefully.

PLEASE PASS TO HOMEOWNER
It should be noted that polyester powder coatings are not maintenance free – the extent of cleaning depends upon the local environment and on the attitude of the building owner. Think cars here...if the building owner wants a finish like that, more regular cleaning is needed. All paints will 'chalk' to some extent and there will be a reduction in gloss level over time – this can be restored.

www.ultraframetrade.co.uk

Ultraframe[®]
Transforming light and space

Job No: 3550 LVL001 01/26 v17

It is Ultraframe's policy to continually seek to improve its products, processes and services, and we reserve the right to change specifications without prior notice. Ultraframe is a trading name of Ultraframe (UK) Limited.